





# Russell Hobbs







instructions

**£10,000 prize draw**  
EXTRA year guarantee  
FREE rewards gallery  
[www.productregister.co.uk/rhobbs](http://www.productregister.co.uk/rhobbs)  
Register online now!  
See back for details



 = dishwasher – top rack






Read the instructions, keep them safe, pass them on if you pass the appliance on.  
Remove all packaging before use.



## **IMPORTANT SAFEGUARDS**

Follow basic safety precautions, including:

- 1 This appliance can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been supervised/instructed and understand the hazards involved.
  - Children shall not play with the appliance.
  - Children must not use the appliance.
  - Keep the appliance and cable out of reach of children.
-  To avoid injury, take care handling the blades, emptying the appliance, and cleaning.
-  Don't add hot liquid (over 40°C), as it may be ejected due to sudden steaming.
- 2 Misuse of the appliance may cause injury.
- 3 Unplug the appliance before assembly, disassembly, or cleaning.
- 4 Unplug the appliance before fitting or removing attachments.
- 5 Don't leave the appliance unattended while plugged in.
- 6 If the cable is damaged, return the appliance, to avoid hazard.
-  Don't put the motor unit in liquid.
- 7 Don't use accessories or attachments other than those we supply.
- 8 Don't use this appliance for any purpose other than making smoothies.
- 9 Don't operate the appliance if it's damaged or malfunctions.
- 10 Don't run the motor for more than 1 minute, or it may overheat. After 1 minute, switch off for at least 2 minutes, to let the motor cool.

### **household use only**



## **BEFORE USING FOR THE FIRST TIME**

- Clean the appliance before using it for the first time.




## **FILLING**

- 1 Sit the motor unit on a dry, firm, level surface.
- 2 Put the plug into the power socket.
- 3 Don't use more than 3 ice cubes.
- 4 Add liquid ingredients first, then solid ones.
- 5 Don't fill the appliance past the 600ml mark.
- 6 Screw the blade unit on to the top of the bottle.
- 7 Turn the bottle upside down.
- 8 Align ▼ on the bottle with ▲ on the motor unit.
- 9 Lower the blade unit into the motor unit.

- 10 Press the bottle down to run the motor.
- 11 Release it to stop the motor.
- 12 For “hands free” operation, turn the bottle left to run the motor, then back, to stop.
- 13 Lift the bottle off the motor unit.
- 14 Turn the bottle right way up.
- 15 Unscrew the blade unit.
- 16 Screw the lid on to the top of the bottle.
- 17 Flip the cap on the lid open to pour, press it closed to store.

## **CARE AND MAINTENANCE**

- 18 Unplug the appliance.
- 19 Wipe the the motor unit with a damp cloth.
- 20 Remove the seal with something blunt, like the handle of a fork.
- 21 Hand wash the removable parts.
- 22 Press the seal back into place with something blunt, like the handle of a fork.
-  You may wash these parts in the top rack of a dishwasher.
- 23 If you use a dishwasher, the harsh environment inside the dishwasher will affect the surface finishes.
- 24 The damage should be cosmetic only, and should not affect the operation of the appliance.

## recipes

**fresh fruit smoothies** – these make 2 large smoothies

### **strawberry & banana smoothie**

150ml milk  
½ banana, roughly chopped  
6 strawberries, stalks removed  
2 ice cubes

### **banana, vanilla & honey smoothie**

200ml milk  
½ banana, roughly chopped  
1 tsp honey  
2 tsp vanilla extract  
2 ice cubes

### **apple & mango smoothie**

300ml apple juice  
½ ripe mango, stoned, peeled and roughly chopped  
3 ice cubes

### **creamy blueberry & vanilla smoothie**

360ml lemonade  
125g vanilla ice cream  
70g blueberries

### **breakfast smoothie**

2 tbsp natural yogurt  
100ml milk  
1 tbsp oatmeal or porridge oats  
½ banana, roughly chopped  
1 tsp honey  
1 apples, cored and roughly chopped  
2 ice cubes

### **chocolate orange smoothie**

170g chocolate ice cream  
300ml orange juice  
2 ice cubes

### **nutty banana smoothie**

75g hazlenut yogurt  
½ banana, roughly chopped  
100ml milk  
2 ice cubes

### **chocolate pear smoothie**

150ml chocolate milk  
1 pear, peeled, cored and roughly chopped  
2 ice cubes

### **mango lassi**

100ml natural yogurt

½ ripe mango, stoned, peeled and roughly chopped

100ml milk

1 tsp honey

2 ice cubes

### **cranberry, orange & banana smoothie**

150ml orange juice

150ml cranberry juice

½ banana, roughly chopped

2 ice cubes

### **peach & apricot smoothie**

2 halves of tinned apricot (in juice)

40ml apricot juice (from tin)

1 peach, stoned, roughly chopped

3 tbsp natural yogurt

100ml milk

1 tsp honey

2 ice cubes

### **berry fruity smoothie**

150ml apple juice

45g raspberries

6 strawberries, stalks removed

2 ice cubes

### **apple, melon & kiwi fruit smoothie**

200ml apple juice

½ kiwi fruit, peeled and roughly chopped

75g melon, roughly chopped

2 ice cubes

### **very chocolatey cherry smoothie**

350ml lemonade

125ml chocolate ice cream

100g cherries, stoned

### **adult only smoothies**

#### **tropical cocktail**

200ml ginger beer

150g melon, roughly chopped

40ml rum

2 ice cubes

#### **cosmopolitan** (makes 2 doubles)

100ml cranberry juice

50ml vodka

50ml cointreau

**baileys coffee cocktail**

100ml milk  
40g vanilla ice cream  
½ tsp instant coffee  
40ml baileys or irish cream liqueur  
3 ice cubes

**strawberry gin fizz**

100ml lemonade  
60ml gin  
1 tsp lemon juice  
6 strawberries, stalks removed  
3 ice cubes

**mango & rum cocktail**

100ml pineapple juice  
¼ ripe mango, stoned, peeled and roughly chopped  
½ banana, roughly chopped  
40ml rum  
2 tbsp natural yogurt  
3 ice cubes

**la mumba**

300ml chocolate milk  
50ml brandy  
3 ice cubes

**pina colada**

200ml pineapple juice  
100ml malibu  
30ml single cream  
4 ice cubes



## ENVIRONMENTAL PROTECTION

To avoid environmental and health problems due to hazardous substances in electrical and electronic goods, appliances marked with this symbol mustn't be disposed of with unsorted municipal waste, but recovered, reused, or recycled.



## SERVICE

If you ring Customer Service, please have the **Model No.** to hand, as we won't be able to help you without it. It's on the rating plate (usually underneath the product).

The product isn't user-serviceable. If it's not working, read the instructions, check the plug fuse and main fuse/circuit breaker. If it's still not working, consult your retailer.

If that doesn't solve the problem – ring Customer Service – they may be able to offer technical advice.

If they advise you to return the product to us, pack it carefully, include a note with your name, address, day phone number, and what's wrong. If under guarantee, say where and when purchased, and include proof of purchase (till receipt). Send it to:

Customer Service

Spectrum Brands (UK) Ltd

Fir Street, Failsworth, Manchester M35 0HS

email: [service@russellhobbs.com](mailto:service@russellhobbs.com)

telephone: 0845 658 9700 (local rate number)

## ➔ GUARANTEE

Defects affecting product functionality appearing within two years of first retail purchase will be corrected by replacement or repair provided the product is used and maintained in accordance with the instructions. Your statutory rights are not affected. Documentation, packaging, and product specifications may change without notice.



## ONLINE

[www.russellhobbs.co.uk](http://www.russellhobbs.co.uk) for more products



## REGISTER ONLINE FOR –

£10,000 prize draw, **EXTRA** year guarantee, **FREE** rewards gallery

Visit [www.productregister.co.uk/rhobbs](http://www.productregister.co.uk/rhobbs)

You must register within 28 days of purchase.

