




Russell Hobbs



instructions

£10,000 prize draw
EXTRA year guarantee
FREE rewards gallery
www.productregister.co.uk/rhobbs
Register online now!
See back for details



Read the instructions, keep them safe, pass them on if you pass the appliance on. Remove all packaging before use.

IMPORTANT SAFEGUARDS

Follow basic safety precautions, including:

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been supervised/instructed and understand the hazards involved.

Children shall not play with the appliance.

Cleaning and user maintenance shall not be done by children unless they are older than 8 and supervised.

Keep the appliance and cable out of reach of children under 8.

 The surfaces of the appliance will get hot.

Don't immerse the appliance in liquid.

If the cable is damaged, return the appliance, to avoid hazard.

- Sit the appliance on a stable, level, heat-resistant surface.
- Keep the appliance and cable away from the edges of worktops.
- Don't use accessories or attachments other than those we supply.
- Don't use the appliance for any purpose other than those described in these instructions.
- Don't use the appliance if it's damaged or malfunctions.

HOUSEHOLD USE ONLY

DIAGRAM

- | | |
|-----------------------------------|---------------------|
| 1. BRITA® MEMO | 8. Permanent filter |
| 2. Water tank lid | 9. Filter handle |
| 3. BRITA® MAXTRA filter cartridge | 10. Filter holder |
| 4. Transit bolt | 11. Hook |
| 5. Filter compartment lid | 12. Carafe |
| 6. Water tank | 13. Filling gauge |
| 7. Scoop | |



BRITA® MAXTRA FILTER CARTRIDGE

- The filter cartridge contains ion exchange resin and activated carbon.
- Reduces limescale and substances, eg. chlorine, that affect taste and odour.
- Reducing the impurities makes the water look and taste better, and the reduction in limescale helps your coffee machine too.
- Remember – water is a food, it goes off. Use filtered water within one day.

BEFORE USING FOR THE FIRST TIME

1. Twist the lid anti clockwise to remove, and expose the reservoir.
2. Turn the red transit bolt anticlockwise and remove it.
3. Fill the reservoir by filling the carafe to $\frac{1}{2}$ mark and pour into the reservoir twice and run the appliance without coffee.
4. Let it cool, discard the water, then use it normally.

PREPARING THE FILTER CARTRIDGE

1. Twist the water tank lid anti clockwise and remove.
2. To remove a used filter cartridge, hold the tank firmly with one hand, grip the ring-pull with the other hand, and pull the filter cartridge up and out.
3. Remove all packaging from the new filter cartridge.
4. Don't worry if the inside of the packaging is damp – it's just condensation.
5. There might be black carbon particles in the packaging or on the filter cartridge. Don't worry, they're harmless.
6. To ensure efficient operation, all air must be removed from the filter cartridge.
7. Submerge the filter cartridge in a bowl of cold water and shake it gently till no more bubbles are released.
8. You may notice some black carbon particles floating in the water. Again, don't worry, they're harmless.
9. Before first use, you must flush the filter cartridge.
10. Push the filter cartridge into the funnel inside the reservoir till it won't go any further.
11. Fill the carafe to the $\frac{1}{2}$ mark and empty it into the tank. Repeat (there's no need to wait for the water to filter through).
12. This will fill the coffee maker to the max capacity.
13. Press and release the  button. The  will show in the display.
14. Shortly afterwards, water will start to drip into the carafe.
15. Discard the water, and repeat the operation.
16. When you've discarded two lots of water, the filter cartridge is ready for use.

RESET THE BRITA® MEMO

This shows what proportion of the filter cartridge's 4 week life is left.

1. Press and hold the START button till all 4 bars appear and flash twice, then let go.
2. Every week, one bar will disappear.
3. When all 4 bars disappear, a flashing arrow will appear at the top of the display. This means it's time to replace the filter cartridge.
4. When the display gets down to one bar, it's a good idea to check that you've got another filter cartridge available. If you haven't, it's time to buy some.
5. The flashing dot at the bottom right of the display shows that the Memo is working.

PREPARATION

1. Sit the appliance on a stable, level, heat-resistant surface.
2. Route the cable so it doesn't overhang, and can't be tripped over or caught.

3. Don't plug it in yet.

FILTER HOLDER




1. To remove, lift the filter holder handle upright and lift the holder up and out.
2. To replace, make sure the handle is upright (fig. A), and lower into the filter compartment.
3. Lower the handle until the hooks on the holder grip the pins in the compartment (fig. B).

FILLING











1. Twist the water tank lid anti clockwise and remove.
2. Remove the carafe from the hotplate.
3. Use the filling gauge printed on the carafe (13) to fill the reservoir.
4. Replace the water tank lid and turn it clockwise to lock.
5. Replace the carafe on the hotplate.
6. Open the filter compartment lid.
7. Fit the permanent filter into the filter holder and add ground coffee.
8. The amount will vary with the type of coffee and individual taste, but we suggest 1 level scoop of filter-ground coffee for each cup using the scoop provided. For a full carafe, use 72g or 12 level scoops.
9. Close the filter compartment lid.
10. Put the plug into the power socket (switch the socket on, if it's switchable).

MAKING COFFEE

If you want coffee straight away:

1. Ignore the clock.
2. Press and release the  button – the  light will show in the display.
3. Shortly afterwards, coffee will start to drip into the carafe.
4. When it's done, the hotplate will keep the carafe warm.
5. If you want to stop the coffee maker while it's brewing, press the  button.

If you want coffee later (timed):

1. Check that the  icon is off. If it isn't, press the  button to turn it off.
2. Set the clock to the correct time. Use the **h** and **min** buttons to set the correct time.
3. Set the timer to the time you want to start brewing.
 - a) Press **and hold** the  button.
 - b) Use the **h** and **min** buttons to set the time you want brewing to start.
4. If you don't press either the **h** or **min** buttons within 5 seconds, the coffee maker will revert to "normal", and the current time will show. Press and hold the  button to start again.
5. When the time is programmed, release the  button then press the  button. The  icon will appear in the display.
6. If you want to check the program time press and release the  button. The programmed time will show for 3 seconds and then return to the time of day.
7. If you want to cancel the timer before brewing has started, press the  button.
8. If you want to stop the coffee maker while it's brewing, press the  button.

KEEP WARM/AUTO SHUT-OFF

1. The coffee maker will keep the coffee warm for about 40 minutes. ☺ and 40:00 will be displayed and will count down in 1 minute increments.
2. 40 minutes after brewing, the ☺ icon will go out and the coffee maker will shut down and the time of day will be displayed.
3. To wake the appliance, press any button.
4. If left for much more than an hour, chemical changes start to affect the flavour of the coffee. It's best to pour it away and make a fresh pot.

A QUICK CUP

If you want a quick cup of coffee before the brewing cycle has finished:

1. You can remove the carafe at any time. The non-drip valve will prevent coffee dripping on to the hotplate.
2. To prevent the filter holder overflowing, replace the carafe on the hotplate within about 20 seconds.
3. When you replace the carafe on the hotplate the non-drip valve opens to let any remaining coffee through.

HOLIDAYS

If you haven't used the coffee maker for a few days empty and rinse out the filter and holder.

Before using the BRITA water filter again take out the cartridge, clean the water tank and funnel thoroughly and repeat the steps described under "PREPARING THE FILTER CARTRIDGE".

TASTE

Don't be tempted to reheat coffee in the appliance. You'll damage the appliance and the coffee will be undrinkable.

CARE AND MAINTENANCE

Clean the filter holder and carafe after each use. Residue from a previous brew will spoil your coffee.

1. Unplug the appliance and let it cool down before cleaning or storing away.
2. Open the filter compartment lid and lift out the filter.
3. Tip the contents of the filter into the bin. Don't flush coffee grounds down the sink. They'll build up and cause a blockage.
4. Lift out the filter holder.
5. You may clean the carafe, permanent filter, and filter holder in warm soapy water. Rinse thoroughly afterwards to remove all traces of soap.
6. Clean the outside surfaces of the appliance with a damp cloth.
7. Replace the filter holder.
8. Drop the filter into the filter holder.
9. Close the lid.



You may wash these parts in a dishwasher.



You may wash these parts in the top rack of a dishwasher.

IMPORTANT INFORMATION

- Always store spare filter cartridges sealed in the original packaging in a shady, cool dry place.
- BRITA water filters are designed for use only with municipally treated tap water (note: This water is constantly controlled and according to legal regulations safe to drink) or with water from private supplies that has been tested as safe to drink. If an instruction is received from the authorities that mains water must be boiled, the BRITA filtered water must also be boiled. When the instruction to boil water is no longer in force, the coffee machine, water tank and funnel must be cleaned and a new cartridge inserted.
- Please filter cold tap water only.
- Clean the water tank and funnel regularly.
- For certain groups of people (e.g. those with impaired immunity and for babies), it is generally recommended that tap water should be boiled; this also applies to BRITA filtered water. Irrespective of the water used, you should use utensils with stainless steel. This product of our BRITA partner meets these requirements. In particular, people who are sensitive to nickel should use appliances with elements made of stainless steel.
- For hygiene reasons, the MAXTRA cartridge contents are subject to special treatment with silver. A very small amount of silver may be transferred to the water. This transference would be within the World Health Organisation (WHO) guidelines.
- During the filtering process, there may be a slight increase in potassium content. However, one litre of BRITA filtered water contains less potassium than e.g. an apple. If you have kidney disease and/or follow a potassium-restricted diet, we recommend that you consult your doctor before using a BRITA water filter. Or call BRITACare Customer Service for further information. Contact details can be found at www.brita.net.
- Should your coffee machine not be in use for a prolonged period (e.g. holiday), BRITA recommends that you take out the cartridge, discard any water left inside the BRITA water filter and loosely insert the MAXTRA cartridge again.
- BRITA filtered water is dedicated for human consumption. It is a perishable food and as such please consume within one day.
- Like each natural product, the consistency of the BRITA MicroporeFilter is subject to natural variances. This can lead to a slight abrasion of small carbon particles into your filtered water, noticeable as black bits. These particles have no negative health effects. If ingested, they will not harm the human body. In case you observe carbon particles, BRITA recommends to flush the cartridge several times or until the black bits disappear.
- BRITA cannot accept responsibility or liability if you do not respect our recommendations for the use and exchange of the BRITA filter cartridge.



ENVIRONMENTAL PROTECTION

To avoid environmental and health problems due to hazardous substances in electrical and electronic goods, appliances marked with this symbol mustn't be disposed of with unsorted municipal waste, but recovered, reused, or recycled.

SERVICE

If you ring Customer Service, please have the Model No. to hand, as we won't be able to help you without it. It's on the rating plate (usually underneath the product).

The product isn't user-serviceable. If it's not working, read the instructions, check the plug fuse and main fuse/circuit breaker. If it's still not working, consult your retailer.

If that doesn't solve the problem – ring Customer Service – they may be able to offer technical advice.

If they advise you to return the product to us, pack it carefully, include a note with your name, address, day phone number, and what's wrong. If under guarantee, say where and when purchased, and include proof of purchase (till receipt). Send it to:

Customer Service

Spectrum Brands (UK) Ltd

Fir Street, Failsworth, Manchester M35 0HS

email: support@russellhobbs.com

telephone: 0845 658 9700 (local rate number)

GUARANTEE

Defects affecting product functionality appearing within two years of first retail purchase will be corrected by replacement or repair provided the product is used and maintained in accordance with the instructions. Your statutory rights are not affected. Documentation, packaging, and product specifications may change without notice.



ONLINE/SPARES

www.russellhobbs.co.uk for more products and/or spares



REGISTER ONLINE FOR –



£10,000 prize draw,

EXTRA year guarantee,

FREE rewards gallery

Visit www.productregister.co.uk/rhobbs

You must register within 28 days of purchase.